

# MFJ-4218MV Instruction Manual

Thank you for purchasing the MFJ-4218MV Switching Power Supply. The MFJ-4218MV has variable output voltage from 0-24Vdc. Output current capacity is 18 Amps intermittent or 13 Amps continuous current at 13.8 VDC.

5-way binding posts and a cigarette lighter socket are provided for output connection. The variable Output Control adjusts output from 0 Vdc to 24 Vdc. The detent position on the Output Control pre-sets the output at 13.8Vdc.

The current meter on the MFJ-4218MV indicates the total current being drawn by the accessories connected to the power supply. The voltage meter on the MFJ-4218MV indicates the voltage set by the voltage control.

The MFJ-4215MV has fault protection for output terminal short or overload. It also provides over temperature protection. If any the above conditions occur, the warning LED will come on. Under fault condition, the power supply will automatically shut off. When the short condition is removed it will reset to the normal condition.

## **Operation:**

Before plugging the MFJ-4218MV in an AC outlet make sure that the proper input AC voltage is set to the correct AC voltage you are using. This is an internal setting. Remove the cover to made AC voltage setting. Select 115 for 100/110/120 AC operation or select 230 for 200/220/240 ac operation. 115V is the default factory setting.

Do not connect any device to the power supply yet. Turn the power supply ON. Set the output voltage by adjusting the variable output control in front of the power supply. The MFJ-4218MV has variable output adjustment from 0 Vdc to 24 Vdc. The control will set same output voltage for output connectors. The detent position on the control is set for 13.8Vdc. Turn OFF the power supply after setting the output voltage.

Connect the loads to any of the output connectors. Positive to positive terminal and negative to negative terminal. Reversed connection will damage your equipment. Connect the devices to the power supply then turn ON the power supply.

# MFJ LIMITED 12-MONTH WARRANTY

MFJ Enterprises, Inc. Warrants to the original owner of this product, if manufactured by MFJ Enterprises, Inc. and purchased from an authorized dealer or directly from MFJ Enterprises, Inc. to be free from defects in material and workmanship for a period of 12 months from date of purchase provided the following terms of this warranty are satisfied.

1. The purchaser must retain the dated proof-of-purchase (bill of sale, canceled check, credit card or money order receipt, etc.) describing the product to establish the validity of the warranty claim and submit the original of machine reproduction or such proof-of-purchase to MFJ Enterprises, Inc. at the time of warranty service. MFJ Enterprises, Inc. shall have the discretion to deny warranty without dated proof-of-purchase. Any evidence of alteration, erasure, or forgery shall be cause to void any and all warranty terms immediately.
2. MFJ Enterprises, Inc. agrees to repair or replace at MFJ's option without charge to the original owner any defective product under warranty, provided the product is returned postage prepaid to MFJ Enterprises, Inc. with a personal check, cashiers check, or money order for \$8.00 covering postage and handling.
3. This warranty is NOT void for owners who attempt to repair defective units. Technical consultation is available by calling (662) 323-0549.
4. This warranty does not apply to kits sold by or manufactured by MFJ Enterprises, Inc.
5. Wired and tested PC board products are covered by this warranty provided on the wired and tested PC board product is returned. Wired and tested PC boards installed in the owner's cabinet or connected to switches, jacks, or cables, etc. sent to MFJ Enterprises, Inc. will be returned at the owner's expense un-repaired.
6. Under no circumstances is MFJ Enterprises, Inc. liable for consequential damages to person property by the use of any MFJ products.
7. Out-of-warranty Service: MFJ Enterprises, Inc. will repair any out-of-warranty product provided the unit is shipped prepaid. All repaired units will be shipped COD to the owner. Repair charges will be added to the COD fee unless other arrangements are made.
8. This warranty is given in lieu of any other warranty expressed or implied.
9. MFJ Enterprises, Inc. reserves the right to make changes or improvements in design or manufacture without incurring any obligation to install such changes upon any of the products previously manufactured.
10. All MFJ products to be serviced in-warranty or out-of-warranty should be addressed to MFJ Enterprises, Inc., 300 Industrial Park Road, Starkville, Mississippi 39759, USA and must be accompanied by a letter describing the problem in detail along with a copy of your dated proof-of-purchase.
11. This warranty gives you specific rights, and you may also have other rights which vary from state to state.