



EBP-7NAZ
Ni-Cd Battery Pack 7.2V 700m AH
EBP-9NAZ
Ni-Cd Battery Pack 7.2V 500m AH



EBP-14N
Thin Type Ni-Cd Battery Pack 7.2V 400m AH



EBP-22N
Ni-Cd Battery Pack 12V 700m AH



120V 220V
EDC-10/6
A.C. Wall Charger for EBP 7NAZ/9NAZ



120V 220V
EDC-24/25
A.C. Wall Charger for EBP-14N/16N/18N/20N/22N



EBP-8NAZ
Ni-Cd Battery Pack 12V 700m AH



EBP-16N
Ni-Cd Battery Pack 7.2V 700m AH



EDH-1
Dry Cell Battery Case



120V 220V
EDC-11/12
A.C. Wall Charger for EBP-8NAZ



120V 220V
EDC-34/35
AC/DC Quick Charge for EBP-10NA/12AN/14N/18N/20N/22N



EBP-10N
Ni-Cd Battery Pack 7.2V 700m AH
EBP-10NA
Ni-Cd Battery Pack 7.2V 700m AH (can be used with Quick Charger)




EBP-18N
Ni-Cd Battery Pack 12V 600m AH



EDH-5
Dry Cell Battery Case



120V 220V
EDC-21/17
A.C. Wall Charger for EBP-10N/10NA



EME-4
Earphone Microphone With PTT



EBP-12N
Ni-Cd Battery Pack 12V 700m AH
EBP-12NA
Ni-Cd Battery Pack 12V 700m AH (can be used with Quick Charger)



EBP-20N
Ni-Cd Battery Pack 7.2V 700m AH



EDH-6
Dry Cell Battery Case




120V 220V
EDC-22/18
A.C. Wall Charger for EBP-12N/12NA




EME-6
Earphone


DESCRIPTION	MODEL NO.	NI-CD BATTERY PACK								DRY CELL CASE			WALL CHARGER				EARPHONE MICROPHONE						
		EBP-7NAZ EBP-9NAZ	EBP-8NAZ	EBP-10N EBP-10NA	EBP-12N EBP-12NA	EBP-14N	EBP-16N	EBP-18N	EBP-20N	EBP-22N	EDH-1	EDH-5	EDH-6	EDC-10/6	EDC-11/12	EDC-21/17	EDC-22/18	EDC-24/25	EDC-34/35	EME-4	EME-6	EME-11	
DJ-120T/E		•	•										•	•									
DJ-160T/E • DJ-460T/E				•	•					•					•	•			•	•	•	•	
DJ-162TD/ED				•	•					•					•	•			•	•	•	•	
DJ-560T/E				•	•					•					•	•			•	•	•	•	
DJ-FIT/E • DJ-F4T/E						•	•	•			•							•	•	•	•	•	
DJ-S1T/E • S4T/E • DJ-S1C/S4C						•	•	•			•							•	•	•	•	•	
DJ-580T/E								•	•				•					•	•	•	•	•	



EMS-22
Speaker Microphone



EDC-13
Mobile DC Power Cable



EDC-43
Mobile DC Power Cable



ESC-10
Soft Case
(EBP-10N or 10NA)




ESC-17
Soft Case
(EBP-20N)



EMS-8
Remote Control Speaker
Microphone




EDC-26
Mobile DC Power Cable with
Active Noise Filter




EJ-6U
Tone Squelch Unit



ESC-11
Soft Case
(EBP-10N or 10NA)




EBC-5
Shoulder Belt with
Case



EDC-2
Mobile DC Power Cable



EDC-36
Mobile DC Power Cable with
Active Noise Filter



EJ-10U
DTMF Encoder/Decoder
Unit




ESC-13
Soft Case
(EBP-7NAZ)




ESK-1
ESK-2
DTMF Key Pad



EDC-8Z
Mobile DC Power Cable with
Noise Filter




EDC-37
Cable for Power Supply
at 13.8V



EJ-12U
Tone Squelch Unit



ESC-14
Soft Case
(EBP-12N or 12NA)



ESC-15
Soft Case
(EBP-14N/16N/18N)

DESCRIPTION MODEL NO.	SPEAKER MICROPHONE			CABLE								UNIT			SOFT CASE					OTHERS			
	HEADSET EME-10/10K	EMS-1Z	EMS-2Z	EMS-8	EDC-2	EDC-8Z	EDC-13	EDC-26	EDC-36	EDC-37	EDC-43	EJ-6U	EJ-10U	EJ-12U	ESC-10	ESC-11	ESC-13	ESC-14	ESC-15	ESC-17	EBC-5	ESK-1 ESK-2	
DJ-120T/E		•			•	•											•						
DJ-160T/E • DJ-460T/E	•		•				•	•				•			•			•					
DJ-162TD/ED	•		•				•	•				•			•			•					
DJ-560T/E	•		•				•	•									•						
DJ-F1T/E • DJ-F4T/E	•		•	•					•	•	•			•						•		•	
DJ-S1T/E • S4T/E • DJ-S1C/S4C	•		•	•					•	•	•		•	•						•		•	※1
DJ-580T/E	•		•	•					•	•	•			•	•					•			※2

Note ※1 T version Standard Accessories ※2 ESK-1 for DJ-S1T/E • S4T/E
E version Optional Accessories ESK-2 for DJ-S1C/S4C